

2004 Toyota Prius

SYSTEM WIRING DIAGRAMS

Fig. 26: 1.5L, Engine Controls Circuit (2 of 4)

